

# Reader Unreachable?

If your Stripe Reader fails to take a payment and gives you this error.

**Reader Error [R]: Processing Error Reader is currently unreachable, please ensure the reader is powered on and connected to the internet before retrying your request.**

First check that the reader is on. Then open the settings by swiping right from the left corner of the screen. When asked the Admin PIN is . Go to Network to make sure it is connected to your Wifi.

If both are true it may be an issue with Stripe. This is a rare occurrence that their server connecting to terminals is down. Wait 10 minutes and try again. These issues are typically resolved quickly.

---

Revision #1

Created Fri, Mar 31, 2023 6:23 PM by [Joe](#)

Updated Fri, Jul 19, 2024 2:49 PM by [Joe](#)